

Installation of the Remineralization Pre-Filter

1. Cut the tubing leading to the ionizer at the desired location and length.
2. The cap on top of the filter housing is marked "OUT" and "IN".



3. The tubing coming from the Reverse Osmosis Post Filter connector needs to be inserted into the side of the housing marked "IN". Firmly press the tubing into the filter-housing cap. You will feel the tubing stop when it is fully inserted. Pull on the tubing gently to ensure that it does not come out and a good connection was made.



4. Insert the tube going to the ionizer into the side of the housing marked "OUT" by firmly pressing the tube into the filter housing cap.
5. To remove the tubing from the filter cap, press in on the O-ring and tubing simultaneously, then gently pull out on the tubing.



Technical Support: 866.321.3116 / 760.585.1692
www.Lifelionizers.com/Support